モーニングコール・目覚まし時計のあわせ方



目覚まし時計の合わせかた

1）時刻調整釦を押し、ご希望の目覚まし時刻に合わせてください。右側の黄色の表示が目覚まし時刻です。
右側の釦を押すと表示時刻が送られ、左側の釦を押すと時刻が戻されます。
このとき、AM(午前)・PM(午後)表示を間違えないようにご注意ください。

2）目覚ましスイッチを押します。目覚まし時刻表示の上に“ALARM”表示が出れば目覚ましセットは完了です。

ご注意

・時刻調和釦を押すと現在時刻表示が一時的に消えますがこれは故障ではありません。

モーニングコール

お手元の電話機による自動セットをご利用ください。

［セット］ 朝 8:00AM にセットする場合
31-0800
夜 8:35PM にセットする場合
31-2035

［取消し］ 30 のみ
（セット時刻はプッシュ不要）

メッセージ

ナイトテーブルのメッセージランプが点滅している場合は、伝言をフロントにてお預かりしております。
ダイヤル 6 番をおまわしください。

目覚まし時計の止めかた

目覚まし音を切るときは、目覚ましスイッチを押します。目覚まし時刻表示の“ALARM”表示が消え、音が切れます。

RIHGA ROYAL HOTEL NIIHAMA

WAKE-UP SERVICE



OPERATION FOR ALARM WAKE-UP

1） Press the Time Adjust Buttons,untill the correct time appears on the Time Display.
To forward the displayed time,press the "FWD" and to reverse the displayed time,press the "REW" . Make sure the AM or PM setting is correct.

2） Press the Alarm Switch to "ON" ,then the Alarm Indicator lights up.

Note:

・When pressing the Time Adjust Button, the display of the present time temporrarily goes out,which dose not mean any defect.

WAKE-UP SERVICE

Please use the telephone AUTO-SET.
Press Key 31,then set the desired time using the keypad.
For example ： 8:00a.m. 31-0800
8:35p.m. 31-2035
To cancel,simply press 30.
You can also set the wake-up call function on the night-table-clock.

MESSAGE

Message for you.Please dial 6.

TO STOP THE ALARM SOUND

Press the Alarm Switch.
Alarm Indicator will disappear and the sound will turn off.

RIHGA ROYAL HOTEL NIIHAMA